







DE VILLE

PRESTIGE QUARTZ 27.4 MM

Red gold on red gold

Caliber
1376

424.50.27.60.05.002

-  Quartz
-  Sapphire crystal
-  Gold 750‰ (18K)
-  Water-Resistant to a relative pressure of 3 bar (30 metres/100 feet)




WATCH FUNCTIONS

The crown has 2 positions:


1. Normal position (wearing position): when the crown is positioned against the case, the crown ensures that the watch is water-resistant.

2. Time setting: hours – minutes. Pull the crown out to position 2. Turn the crown forwards or backwards. Push the crown back to position 1.



FOLDOVER CLASPS

Using the fine length adjuster (fig. 5)



Using the diving extension (fig. 6)

Note: to fold the diving extension away, it is important to proceed according to fig. 6.2 (with the diving extension perpendicular to the cover of the clasp).

